



1.) HAND TIGHTEN BOLTS ON BOTH SIDES OF THE CLAMP. MAINTAIN GAPS OF EQUAL DISTANCE.

2.) APPLY AN EXTRA 1/2 TURN AS SOON AS THE BOLT STARTS TO FEEL TIGHT.

3.) MAXIMUM TORQUE SETTING:
15 LBF-IN / 1.7 KGF-M

